


Sling Laundry/Maintenance Instructions



- Machine Wash, Normal, High Heat
- Tumble Dry, Normal, No Heat
- Do Not Bleach
- Do Not Iron



1

All the loops and straps on each side must be free of fraying or cuts. Stitching must be intact.



2

Stitching in seams and panels must also be intact.



3

Fabric must be free of worn spots, weave separation or visible cuts.